



Parts Diagram for AREXP33/45/55



1. ARSP110	Press Button with Spring	8. ARSP117	Upper Pipe C EXP45
2. ARSP111	Plastic guide for EXP Series	9. ARSP119	Endcap for B Pipe
ARSP111A	Guide Set for EXP45 (6pcs)	10. ARSP120	Endcap for C Pipe
ARSP111B	Guide Set for EXP55 (8pcs)	14. ARSP103	B Pipe for EXP55
ARSP111C	Guide Set for EXP33 (5pcs)	15. ARSP104	C Pipe for EXP55
3. ARSP113	Stopper Set B for EXP Poles	17.	B Pipe for EXP33
7. ARSP116	Mid Pipe B for EXP45	18.	C Pipe for EXP33

*Parts in grey not stocked



- | | | |
|-----|---------|-------------------------------------|
| 3. | ARSP112 | Lower Alum Pole (A Pipe) AREXP45 |
| 5. | ARSP114 | Stopper Set Of A Pipe for EXP Poles |
| 6. | ARSP115 | Screw for End cap A (2 pcs) |
| 11. | ARSP121 | End cap A with 2 screws |
| 12. | | Grip cover for A pipe |
| 13. | ARSP102 | A Pipe for EXP55 |
| 16. | | A Pipe for EXP33 |
| 19. | | Rubber cushion for EXP Series |
| 20. | | Screw for EXP Series |