


Parts Diagram for ARSE45

Blade: ARSE45-1 Replacement Blades - ARSE45



-
- | | |
|------------|---|
| 1. ARSP188 | Replacement Spring for ARSE30/45/45B |
| 2. | Grip for ARSE45 |
| 3. ARSP190 | Replacement Screw/Nut for ARSE30/45B |
| 4. ARSP161 | Replacement Rubber Strap for AR310/300L |

*Parts in grey not stocked