


Parts Diagram for ARLPA30L Lopper

Blade:	ARLPA301	Replacement Blade for ARLPA30L
	ARLPA302	Replacement Anvil for ARLPA30L



- | | | |
|----|---------|---|
| 1. | ARSP382 | Centre Bolt for ARLPA30L |
| 2. | ARSP383 | Centre Nut For ARLPA30L |
| 3. | ARSP384 | Link for ARLPA30L |
| 4. | ARSP385 | Fulcrum Bolt of Link for ARLPA30L |
| 5. | ARSP386 | Link Spacer for ARLPA30L |
| 6. | ARSP387 | Blade Holding Bolt, Nut & Washer for ARLPA30L |
| 7. | ARSP388 | Blade Holding Socket LPA30L |
| 8. | | Pipe with grip for ARLPA30L |

*Parts in grey not stocked